

DDMWorks Backbone Brace



Stronger, better, faster... The new DDMWorks backbone installs under the car to box in and stabilize the center of the car. This results in a more solid and stable platform for the suspension to work from, improving handling and making the car more solid.

Product Enclosed:

- Street Version, 1/4 inch thick
 Extreme Version, 1/2 inch thick
 Race Version, 3/8 inch thick

INSTALLATION IS EASY!



TOOLS NEEDED

- 13mm socket wrench
- 15mm socket wrench

PACKING LIST

- Race/Street: Use stock hardware, no additional hardware needed.
- Extreme: 12 M8x40 Hex Flange Bolt

To Install:

Using a 13mm socket wrench remove stock brace and replace with DDMWorks Backbone Brace. Manufacturer states the torque specs are 13-15 lb/ft but tightening them snugly will do just fine. Over tightening can result in a broken bolt.

It may be necessary to loosen your exhaust for installation. For this you will need a 15mm socket wrench. Before removing these bolts we strongly suggest you apply WD40 or PB Blaster a couple of times to keep these bolts from ceasing as you remove them.