

# DDMworks Big Caliper fitment without 3/16" wheel spacer

To use this template:

Glue the printout to a piece of stiff paper or cardboard and cut out the template.

On the back side of the wheel, put the "wheel center" section into the hole in the center of the wheel. If the template clears the inside of the wheels, the big brake kit will fit.

Use these scales to make sure your printout is the correct size. If not, please check your printer settings. (Dimensions are in inches)

