



Slingshot Sway Bar End Links



Installation time of the Sway Bar End Links depends on you and your mechanical skills. It is suggested that you read through the directions a few times to familiarize yourself with the components of the kit, and your car.

If you are pretty handy with tools the End Links can be installed in 30 minutes, however we suggest that you schedule at least a couple of hours for the installation.

If you have any questions during the installation you can call us at (864) 907-6004 or email us at Tech@ddmworks.com.

TOOLS NEEDED

15mm wrench
17mm wrench
8mm allen wrench



119-A Hwy 183
Piedmont, SC 29673

Tech Support

(864) 907-6004 (call or text)

Tech@DDMWorks.com

Rev A 5-6-15 ZPS

Removing the Stock Sway bar end links

1. Make sure your Slingshot is in neutral and the parking brake is on before starting installation.
2. You can start on either side of the Slingshot but it is recommended you do one link at a time.
3. To remove the stock sway bar end links you will use a 15mm wrench and a 17 mm wrench. Remove both bolts, one holding the end link to the sway bar, the other holding the link to the control arm. You will not reuse any of these parts.



Installing The DDMWorks Sway Bar End Links

1. Starting with the top of the new sway bar end link and bolting it onto the sway bar. Insert the bolt through the sway bar end link, place the black cone spacer onto the bolt with the narrow end toward the end link. Next put the green washer over the bolt. The bolt can now go through the sway bar. Finish with the silver washer and locking nut.



2. For the bottom bolt that goes through the control arm you will use the m10x90 bolt. Insert the bolt through the new sway bar end link. Followed by the black cone spacer, again with the narrow end toward the end link. The bolt can then go through the control arm. Finish with a silver washer and locking nut.



3. Repeat the same process on the other side of the Sway Bar and the install is complete. Make sure everything is tightened down and enjoy.

Congratulations! You have finished the install. All of us here at DDMWorks thank you for your purchase and hope you enjoy your new sway bar end links.

If you have any questions feel free to give us a call or text us at 864-907-6004. You can also email us at Tech@ddmworks.com.



119-A Hwy 183
Piedmont, SC 29673
Tech Support
(864) 907-6004 (call or text)
Tech@DDMWorks.com

Also, Follow us on Facebook for the latest product and information releases!

Rev A 5-6-15 ZPS

Adjusting The Sway Bar End Links

To adjust your DDMWorks Sway Bar End links, Remove the bolts holding the link on. Using a 17mm wrench loosen the lock nut and twist the adjuster out to the desired length. Tighten the lock nut back down and reinstall the mounting bolts.

