



Billet Aluminum Oil Cap—2020+ Slingshot DDM-20-11



This DDMWorks billet aluminum Oil cap for the 2020+ Slingshot installs easily and helps give the engine bay a more finished and unique look.

If you are pretty handy with tools the caps can be installed in just a couple of minutes.

If you have any questions during the installation you can call or text (864) 907-6004. Email support is also available - Tech@ddmworks.com.

Tools Needed for Install

- Allen key needed for install is included in the kit, no other tools necessary.

DDMWorks - 119A Hwy 183
Piedmont, SC 29673
Tech Support Call, Text or Email:
(864) 907-6004,



Installation of billet aluminum oil cap—2020+ Slingshot

1. Installation of the oil cap is quick and easy to do. First, find the oil cap on the top of the engine.
2. Remove the cap by loosening the cap about a half turn until it stops stop, then pull up to remove the cap from the Slingshot. Wipe the cap down to remove any oil.
3. In the hardware pack you will see 3 set screws, use the supplied Allen key to start the set screws into the 3 threaded holes along the side of the billet cap.
4. Install the billet cap over the stock plastic cap, make sure to line the set screw up with a depression in the stock plastic cap, which will help hold the cap in position better. Once the cap is lined up, tighten all 3 set screws evenly until they are snug, they do not have to be torqued down.
5. Re-install the new oil cap onto the engine and tighten. If you want to change the direction the billet cap points, you can loosen the set screws on the cap, rotate to the next depression, tighten and check again. Once you are happy with the alignment, enjoy!



Congratulations! Install is complete!



If you have any questions feel free to give us a call or text us at 864-907-6004. You can also email us at Tech@ddmworks.com.