



DDMWorks 2020+ Prostar Coil Cover DDM-23-35



This stainless steel coil cover adds some color and also cleans up the looks under the hood of your Slingshot.

If you are pretty handy with tools this coil cover can be installed in about 15 minutes, however we suggest that you schedule at least 1 hour for the installation.

If you have any questions during the installation you can call or text (864) 907-6004. Email support is also available - Tech@ddmworks.com.

Tools Needed for Install

- 13mm socket and driver
- Wire cutters
- 5mm Allen Key
- Loctite (suggested)

DDMWorks - 119A Hwy 183 Piedmont, SC 29673
Tech Support Call, Text or Email: (864) 907-6004, Tech@DDMWorks.com

Installation of the Coil Cover

IMPORTANT STEPS BEFORE STARTING ANY INSTALLATION!

1. Make sure your engine is cool to the touch

1. After opening the hood of your Slingshot, find the coolant hose that comes up through the center of the engine and goes to the coolant tank. This hose is held to the wire harness with a zip tie. Use a wire cutter to carefully cut the zip tie holding the hose and remove the zip tie from the wire harness and the hose.
2. After cutting off the zip tie, install the corrugated plastic protector over the hose that you cut the zip tie off of. To install the plastic protector, open the protector up and slide it onto the hose. There is a metal clip on the hose close to the engine, slide the corrugated plastic protector up to that metal clip.
3. Install the aluminum hex shaped spacers onto the studs sticking up on cylinder #2 and cylinder #4 coil packs (as counted from the front of the engine). Screw the spacers down by hand, then use the 13mm socket to snug them, they do not need to be over tightened. If you have some loctite, a small drop on the threads of the spacers before installing will help to secure them.



Installation of the Coil Cover—continued

4. With the hex spacers installed, set the coil cover onto the engine. There is a cut out on the passengers side of the coil cover that the coolant hose goes through. Line the 2 holes on top of the coil cover with the spacers installed earlier and secure with the 2 included bolts. Use a washer under the head of both bolts and then tighten using a 5mm Allen key. A small drop of loctite on the threads is suggested.



Congratulations!

You have finished the install. All of us here at DDMWorks thank you for your purchase, support and hope you enjoy your new installation. If you are enjoying them, we really appreciate you letting us and others know on Facebook, Slingshotinfo forum or other Social Media. If there is anything we can do to help you more, please let us know by contacting us -

**Call or text us 864-438-4949 or 1-833-DDMWorks
Techline/After hours -864-907-6004.
You can also email us at Tech@ddmworks.com.**

