

Disc Rotor Orientation of DBA Slotted Rotors

DBA Slotted rotors are directional and should be fitted to the vehicle as follows:

All DBA slotted rotors are sold as:

SL – SLOTTED LEFT and **SR – SLOTTED RIGHT**.

As a general rule, we recommend to install the **SL disc to the LEFT SIDE of the vehicle** and the **SR to the RIGHT SIDE of the vehicle** as per the image below.

(However, slotted discs can be fitted with slots facing in the opposite directions without any detriment to braking performance)

If you need to check if the rotors have been fitted correctly, view the disc fitted to the right side of the vehicle, the slots should taper as per the **RIGHT DISC** image above. Now view the disc fitted to the left side of the vehicle, the slots should taper as per the **LEFT DISC** image above.

